

Dissolvable Seam Laundry Bags



The ultimate in minimizing cross contamination. **Dissolvable Seam Laundry Bags** allows foul, infectious or cytotoxic linen to be placed into the bag and eliminate further manual handling.

FEATURES & BENEFITS

- ▶ Ultimate Infection Control
- ▶ Ideal for Aged Care, Prisons, Hospitals & Hotels
- ▶ Made from PE Used bag is fully recyclable

Comes standard with a soluble tie to close the bag and eliminate transfer via the air and keeps items secure ready for washing.

INSTRUCTIONS

The bag is placed directly into the washing machine eliminating contact of foul, infectious or cytotoxic linen coming into contact with the facility personnel between source and disinfection during the wash cycle.

SPECIFICATIONS

- ▶ 720mm Wide
- ▶ 990mm High
- ▶ 25 micron thickness
- ▶ Red
- ▶ 250 per carton

Dissolvable Seam Laundry Bags



CONTROL PROCESS

Dissolvable Seam Laundry Bags are an essential part of any effective infection control process.

One of the areas of greatest risk of infection is soiled linen. Whether handling linen, or clothing that is either contaminated with body fluids, cytotoxic or considered infectious, it is vital to eliminate the risk of cross infection to staff and other people.

SAFE ISOLATION

Opera Dissolvable Seam Laundry Bags meets duty of care guidelines by ensuring the safe isolation, transportation and disinfection of foul, infectious or cytotoxic linen.

The filled Dissolvable Seam Laundry Bags are sealed with its water soluble tie which is already adhered in place on each bag ready for quick and efficient sealing of the bag ready for transfer to the laundry.

THE WASH CYCLE

Bags are then placed unopened into the washer. Within 30 seconds of the wash the soluble seam dissolves along with the tie, releasing the contents of the bag to be washed.

At the end of the wash cycle the linen is removed for drying and the Dissolvable Seam Laundry Bags are now a clean disinfected sheet of PE film which is removed and discarded preferably to your recycling waste rather than general land fill waste.

The Dissolvable Seam Laundry Bag is ideal for any type of foul, infectious or cytotoxic linen, and suitable for hot and cold washes.

The external membrane is not affected by damp, soiled linen as it is protected from the inside by a layer of impermeable plastic. By treating all soiled linen as potentially infectious, the incidence of infection can be significantly reduced.